

Fire Service/FEO Key Switch Parts

*All FEO Key Switches use FEO-K1 key and all FEO Key Switches come with 2 FEO-K1 keys

■ Please see Fire Service Key Function chart on pg 248



Universal

S.E.E.S. #	Description
FEO-EP-UNV-001	FEO Fire Service Key Switch, Universal Emergency Power, 3 Pos, Rmv3, (Auto-1-2)
FEO-UNV-001	FEO Fire Service, Universal PH 1, 3 Pos, Rmv2 (Byp-Off-On)
FEO-UNV-001R	FEO Fire Service, Universal PH 1, 3 Pos, Rmv2 (Reset-Off-On)
FEO-UNV-002	FEO Fire Service, Universal PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-UNV-003	FEO Fire Service, Universal 2 Pos, Rmv 2 (Off-On)



FEO-UNV-003

Traditional

S.E.E.S. #	Description
FEO-TR-001H	FEO Fire Service, Traditional, H PH 1, 3 Pos, Rmv2 (Byp-Off-On)
FEO-TR-001V	FEO Fire Service, Traditional, V PH 1, 3 Pos, Rmv2 (Byp-Off-On)
FEO-TR-001HR	FEO Fire Service, Traditional, H PH 1, 3 Pos, Rmv2 (Reset-Off-On)
FEO-TR-001VR	FEO Fire Service, Traditional, V PH 1, 3 Pos, Rmv2 (Reset-Off-On)
FEO-TR-002H	FEO Fire Service, Traditional, H PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-TR-002V	FEO Fire Service, Traditional, V PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-TR-003H	FEO Fire Service, Traditional, H 2 Pos, Rmv2 (Off-On)
FEO-TR-003V	FEO Fire Service, Traditional, V 2 Pos, Rmv2 (Off-On)
FEO-TR-SPECIAL	FEO Fire Service, Traditional, Special, Fill out Form




FEO-TR-001H

Impulse

S.E.E.S. #	Description
FEO-IMS-001H	FEO Fire Service, Impulse, Sq., H PH 1, 3 Pos, Rmv2 (Byp-Off-On)
FEO-IMS-001V	FEO Fire Service, Impulse, Sq., V PH 1, 3 Pos, Rmv2 (Byp-Off-On)
FEO-IMS-001HR	FEO Fire Service, Impulse, Sq., H PH 1, 3 Pos, Rmv2 (Reset-Off-On)
FEO-IMS-001VR	FEO Fire Service, Impulse, Sq., V PH 1, 3 Pos, Rmv2 (Reset-Off-On)
FEO-IMS-002H	FEO Fire Service, Impulse, Sq., H PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-IMS-002V	FEO Fire Service, Impulse, Sq., V PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-IMS-003H	FEO Fire Service, Impulse, Sq., H 2 Pos, Rmv2 (Off-On)
FEO-IMS-003V	FEO Fire Service, Impulse, Sq., V 2 Pos, Rmv2 (Off-On)
FEO-IMR-SPECIAL	FEO Fire Service, Impulse, Sq., Special
FEO-IMR-001H	FEO Fire Service, Impulse, Rn, H PH 1, 3 Pos, Rmv2 (Byp-Off-On)
FEO-IMR-001V	FEO Fire Service, Impulse, Rn, V PH 1, 3 Pos, Rmv2 (Byp-Off-On)
FEO-IMR-001HR	FEO Fire Service, Impulse, Rn, H PH 1, 3Pos, Rmv2 (Reset-Off-On)
FEO-IMR-001VR	FEO Fire Service, Impulse, Rn, V PH 1, 3Pos, Rmv2 (Reset-Off-On)
FEO-IMR-002H	FEO Fire Service, Impulse, Rn, H PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-IMR-002V	FEO Fire Service, Impulse, Rn, V PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-IMR-003H	FEO Fire Service, Impulse, Rn, H 2 Pos, Rmv2 (Off-On)
FEO-IMR-003V	FEO Fire Service, Impulse, Rn, V 2 Pos, Rmv2 (Off-On)



FEO-IMS-001HR



FEO-IMR-001HR

FEO-IMS-002V

Innovation

S.E.E.S. #	Description
FEO-INS-001	FEO Fire Service, Innovation, Sq, PH 1, 3 Pos, Rmv2 (Byp-Off-On)
FEO-INS-001R	FEO Fire Service, Innovation, Sq, PH 1, 3 Pos, Rmv2 (Reset-Off-On)
FEO-INS-002	FEO Fire Service, Innovation, Sq, PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-INS-003	FEO Fire Service, Innovation, Sq, 2 Pos, Rmv 2 (Off-On)
FEO-INR-001	FEO Fire Service, Innovation, Rn, PH 1, 3 Pos, Rmv2 (Byp-Off-On)
FEO-INR-001R	FEO Fire Service, Innovation, Rn, PH 1, 3 Pos, Rmv2 (Reset-Off-On)
FEO-INR-002	FEO Fire Service, Innovation, Rn, PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-INR-003	FEO Fire Service, Innovation, Rn, 2 Pos, Rmv2 (Off-On)
FEO-INR-SPECIAL	FEO Fire Service Key Switch, Innovation Rn Special Order



FEO-INS-002



Fire Service/FEO Keys Switch Parts

*All FEO Key Switches use FEO-K1 key and all FEO Key Switches come with 2 FEO-K1 keys

■ Please see Fire Service Key Function chart on pg 248



FEO-WB-001



FEO-WB-002



FEO-WB-003



FEO-AU-001R



FEO-US-001



FEO-GAL-002V



FEO-AD-002

Westinghouse

S.E.E.S. #	Description
FEO-WB-001	FEO Fire Service, Westinghouse PH 1, 3 Pos, Rmv2 (By-Off-On)
FEO-WB-001R	FEO Fire Service, Westinghouse PH 1, 3 Pos, Rmv2 (Reset-Off-On)
FEO-WB-002	FEO Fire Service, Westinghouse PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-WB-003	FEO Fire Service, Westinghouse, 2 Pos, Rmv2 (Off-On)

Dover Aurora

S.E.E.S. #	Description
FEO-AU-001	FEO Fire Service, Aurora, PH 1, 3 Pos, Rmv2 (By-Off-On)
FEO-AU-001R	FEO Fire Service, Aurora, PH 1, 3 Pos, Rmv2 (Reset-Off-On)
FEO-AU-002	FEO Fire Service, Aurora, PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-AU-003	FEO Fire Service, Aurora, 2 Pos, Rmv2 (Off-On)

US

S.E.E.S. #	Description
FEO-US-001	FEO Fire Service, US, PH 1, 3 Pos, Rmv2 (By-Off-On)
FEO-US-001R	FEO Fire Service, US, PH 1, 3 Pos, Rmv2 (Reset-Off-On)
FEO-US-002	FEO Fire Service, US, PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-US-003	FEO Fire Service, US, 2 Pos, Rmv2 (Off-On)
US-KS1-SPECIAL	Fire Service Key Switch, Special #1 Key, Specify Engraving
FEO-USS-001	FEO Fire Service, US, SQ, PH 1, 3 Pos, Rmv2 (By-Off-On)
FEO-USS-002	FEO Fire Service, US, SQ, PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-USS-001R	FEO Fire Service, US, SQ, PH 1, 3 Pos, Rmv2 (Reset-Off-On)
FEO-USS-003	FEO Fire Service, US, SQ, 2 Pos, Rmv2 (Off-On)

GAL

S.E.E.S. #	Description
FEO-GAL-001H	FEO Fire Service, GAL, Rnd, H PH 1, 3 Pos, Rmv2 (By-Off-On)
FEO-GAL-001V	FEO Fire Service, GAL, Rnd, V PH 1, 3 Pos, Rmv2 (By-Off-On)
FEO-GAL-001HR	FEO Fire Service, GAL, Rnd, H PH 1, 3 Pos, Rmv2 (Reset-Off-On)
FEO-GAL-001VR	FEO Fire Service, GAL, Rnd, V PH 1, 3 Pos, Rmv2 (Reset-Off-On)
FEO-GAL-002H	FEO Fire Service, GAL, Rnd, H PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-GAL-002V	FEO Fire Service, GAL, Rnd, V PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-GAL-003H	FEO Fire Service, GAL, Rnd, H 2 Pos, Rmv2 (Off-On)
FEO-GAL-003V	FEO Fire Service, GAL, Rnd, V 2 Pos, Rmv2 (Off-On)

Adams

S.E.E.S. #	Description
FEO-AD-001	FEO Fire Service, Adams, Rn PH 1, 3 Pos, Rmv2 (By-Off-On)
FEO-AD-001R	FEO Fire Service, Adams, Rn PH 1, 3 Pos, Rmv2 (Reset-Off-On)
FEO-AD-002	FEO Fire Service, Adams, Rn PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-AD-003	FEO Fire Service, Adams, Rn 2 Pos, Rmv2 (Off-On)
FEO-ADS-001	FEO Fire Service, Adams, Sq PH 1, 3 Pos, Rmv2 (By-Off-On)
FEO-ADS-001R	FEO Fire Service, Adams, Sq PH 1, 3 Pos, Rmv2 (Reset-Off-On)
FEO-ADS-002	FEO Fire Service, Adams, Sq PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-ADS-003	FEO Fire Service, Adams, Sq 2 Pos, Rmv2 (Off-On)

Fire Service/FEO Key Switch Parts

*All FEO Key Switches use FEO-K1 key and all FEO Key Switches come with 2 FEO-K1 keys

■ Please see Fire Service Key Function chart on pg 248



Payne

S.E.E.S. #	Description
FEO-PN-001	FEO Fire Service, Payne, PH 1, 3 Pos, Rmv2 (By-Off-On)
FEO-PN-001R	FEO Fire Service, Payne, PH 1, 3 Pos, Rmv2 (Reset-Off-On)
FEO-PN-002	FEO Fire Service, Payne, PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-PN-003	FEO Fire Service, Payne, 2 Pos, Rmv2 (Off-On)



FEO-PN-002

Kone

S.E.E.S. #	Description
FEO-KN-001	FEO Fire Service, Kone, PH 1, 3 Pos, Rmv2 (By-Off-On)
FEO-KN-001R	FEO Fire Service, Kone, PH 1, 3 Pos, Rmv2 (Reset-Off-On)
FEO-KN-002	FEO Fire Service, Kone, PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-KN-003	FEO Fire Service, Kone, 2 Pos, Rmv 2 (Off-On)



FEO-KN-001

Schindler

S.E.E.S. #	Description
FEO-SCH-001	FEO Fire Service, Schindler CT, PH 1, 3 Pos, Rmv2 (By-Off-On)
FEO-SCH-001R	FEO Fire Service, Schindler CT, PH 1, 3 Pos, Rmv2 (Reset-Off-On)
FEO-SCH-002	FEO Fire Service, Schindler CT, PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-SCH-003	FEO Fire Service, Schindler CT, 2 Pos, Rmv2 (Off-On)
FEO-SCK-001	FEO Fire Service, Schindler MT, PH 1, 3 Pos, Rmv2 (By-Off-On)
FEO-SCK-001R	FEO Fire Service, Schindler MT, PH 1, 3 Pos, Rmv2 (Reset-Off-On)
FEO-SCK-002	FEO Fire Service, Schindler MT, PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-SCK-003	FEO Fire Service, Schindler MT, 2 Pos, Rmv2 (Off-On)



FEO-SCK-002

Otis

S.E.E.S. #	Description
FEO-OB-001	FEO Fire Service, Otis M1, PH 1, 3 Pos, Rmv2 (By-Off-On)
FEO-OB-001R	FEO Fire Service, Otis M1, PH 1, 3 Pos, Rmv2 (Reset-Off-On)
FEO-OB-002	FEO Fire Service, Otis M1, PH 2, 3 Pos, Rmv2 (Off-Hold-On)
FEO-OB-003	FEO Fire Service, Otis M1, 2 Pos, Rmv2 (Off-On)
FEO-OB-SPECIAL	FEO Fire Service, Otis M1, Special



FEO-OB-001

OEM Cylinder

S.E.E.S. #	Description
FEO-KS1	Fire Service Key Switch, FEO PH 1, 3 Pos, 2Pull
FEO-KS1A	Fire Service Key Switch, FEO PH 1 3 Pos 2 Key Pull, Flats 9 & 3
FEO-KS1B	Fire Service Key Switch, FEO PH 2 3 Pos 2KP, Ext Slotted Shaft
FEO-KS2	Fire Service Key Switch, FEO PH 2, 3 Pos, 2Pull
FEO-KS2A	Fire Service Key Switch, FEO PH 2 3 Pos 2 Key Pull, Flats 9 & 3
FEO-KS2B	Fire Service Key Switch, FEO PH 2 3 Pos 2KP, Ext Slotted Shaft
FEO-KS3	Fire Service Key Switch, FEO 3 Pos, 3 Pull
FEO-KS3A	Fire Service Key Switch, FEO 3 Pos 3 Key Pull, Flats 9 & 3
FEO-KS3B	Fire Service Key Switch, FEO 3 Pos 3KP, Ext Slotted Shaft
FEO-KS4	Fire Service Key Switch, FEO 2 Pos, 2 Key Pull
FEO-KS4A	Fire Service Key Switch, FEO 2 Pos, 2KP, Flats 9 & 3
FEO-KS5A	Fire Serv Key switch, FEO 5 Pos, 5KP, Flats 9 & 3



FEO-KS4



FEO-KBX-001

Standard

S.E.E.S. #	Description
FEO-KBX-001	FEO Key Box, Standard 1-3/8" deep, "FIRE DEPT USE ONLY"

Latching Cylinder

S.E.E.S. #	Description
FEO-FSLC1	FEO Fire Service Latching Cylinder for Cabinet

INNOVATION



INEL-001



INPI-001



INPI-002



INPC-003

Emergency Light

S.E.E.S. #	Description
INEL-001	Emergency light, for Innovation COP III LED Light, 120 VAC uses battery MIS-194Q
MIS-194Q	Battery, replacement for INEL-001

■ See more replacement batteries on page 192.



INKS-001

Position Indicators, Digital

S.E.E.S. #	Description
INPI-001	Digital PI for Innovation style CE MH222-XX
INPI-002	Digital PI for Innovation style IH320-XXXC 120 VAC
INPI-003	Digital PI for Innovation style IH320-XXXF 24-48 VDC with negative signal

Keyswitch

S.E.E.S. #	O.E.M.#	Description
INKS-001	23074	Keyswitch, Innov Run-Stop, 2 pos, 2Kp, 512 key




INPC-007



INPC-002

PC Boards for Pushbutton

S.E.E.S. #	O.E.M.#	Description
INPC-001	5941S1CCV4A	PC Board, for Innovation PB-1 style, multi-volt amber color
INPC-002	59413320-1A	PC Board, for Innovation PB-1 style, 24 VDC amber color
INPC-003	59413320-1A	PC Board, for Innovation PB-1 style, 120 VAC amber color
INPC-004	5941S1CCV4R	PC Board, for Innovation PB-23 style, multi-volt red color
INPC-005	59413320-1R	PC Board, for Innovation PB-23 style, 24VDC red color
INPC-006	59413320-1R 120	PC Board, for Innovation PB-23 style, 120VAC red color
INPC-007	5941S5CCV5W	PC Board, for Innovation lantern arrow style, white non-vandal
INPC-008	5941S5CCV5R	PC Board, for Innovation lantern arrow style, red non-vandal
INPC-009	5941S5CCV5G	PC Board, for Innovation lantern arrow style, green non-vandal
INPC-010	5941S6CCV5W	PC Board, for Innovation lantern tamper 7 LED style, white vandal
INPC-011	5941S6CCV5R	PC Board, for Innovation lantern tamper 7 LED style, red vandal
INPC-012	5941S6CCV5G	PC Board, for Innovation lantern tamper 7 LED style, green vandal



INPC-010

Keys for Key Switches

S.E.E.S #	Key#	S.E.E.S #	Key#
US-KS2B	2	SK-5	H301
US-KS3A	3	WK-2	H200
US-KS4A	4	DKS-74A	H1846
US-KS5A	5	DKS-75A	H1848
DKS-18B	106	DK-4	H2007
DKS-15B	107	DK-5	H2011
GK-2	1617	DK-3	H-2111
GKS-2A	1617	DKS-76A	H-2165
HK-4	2007	DKS-9A-A	H2192
MIS-189Z-A	2642	DKS-12A	H2237
APB-11F	3500	DKS-5A	H-2304
APB-11G	3501	DKS-3A	H-2395
APB-11H	3502	DKS-4A	H-2389
MIS-189Q-A	3502	DKS-6A	H-2454
DKS-14A	5027	DKS-9C-A	H2488
PKS-3A	6304	DKS-7A	H-2567
PKS-8A	6305	DKS-8A	H-2573
PKS-1A	6330	DKS-9B-A	H2399
APB-11I	14398	DKS-21A	H-5009
HK-1	3-4009-51	DKS-13A	H5074
GK-201	0064N	DKS-15A	H5154
GK-200	0063N	DKS-18A	H5140
SK-2	100-T	APB-11B	H7005
MK-2	A-00	APB-11A	J200
MK-3	A-01	APB-11C	K-7048
MK-4	A-02	APB-11D	K-7049
MK-6	A-03	TK-01	L201
MK-1	A-40	TK-02	L202
FEO-K1	ACE	TK-03	L203
HK-5	AE102	TK-04	L204
ASK-200	AKC0053	TK-05	L205
ASK-201	AKC0051	TK-06	L206
ASK-202	AKC0052A	MIS-189G	MFD1
MIS-189P	AUE-5-CCL	MK-15	MK-01
AZFS-KEY	AZFS	MK-16	MK-03
MIS-183A	CAT 74	MK-17	MK-04
DKS-64A	DES-1	MK-11	MK-05
DKS-65A	DES-3	MK-12	MK-06
DKS-66A	DES-4	MK-14	MK-06
DKS-67A	DES-5	MK-18	MK-09
DKS-68A	DES-6	SK-3	OCO-1
DKS-69A	DES-7	SK-4	OCO-4
DKS-70A	DES-9	MIS-189F-A	S.E.E.S. #2
DKS-71A	DES-10	MIS-189H-A	S.E.E.S. #3
MIS-189E-A	EPCO #1	MIS-189T-A	S.E.E.S. #4
MIS-189E-B	EPCO #2	MIS-189V-A	S.E.E.S. #5
MK-10	EX-512	MIS-189S-A	S.E.E.S. #10
MK-9	EX-513	DKS-202	SC1000
MK-19	EX-514	MIS-189-FS-A	SC1000
MK-8	EX-515	APB-11	W7336
MK-13	EX-516	APB-11E	W7320
WB-29A	F59	SK-6	WDO1
GKS-1	G-1601X		
GK-1	G1612X		



MIS-189Q-A



FEO-K1



ASK-202



MIS-189P



AZFS-KEY



MIS-189E-A



MIS-189G



MIS-189V-A



MIS-189-FS-A